

AudioBox™ 22/44VSL



PreSonus® www.presonus.com

Virtual StudioLive
Studio One Artist



14.

().



PreSonus,
PreSonus

support@presonus.com



www.presonus.com.

15.



16.



RoHS

2011/65/EC

1.

ROHS.

2.

3.

REACH

4.

EC1907 / 2006

5.

(REACH)

6.

0,1%

7.

WEEE

8.

(),



9.

10.

11.

PreSonus.

CE

12.

EMC (2006/95 /)
(2004/108 / EC).



13.

AudioBox™ 22/44VSL

1.0 — 1

1.1 — 1

1.2 AudioBox 22/44VSL — 2

1.3 Studio One Artist — 2

1.4 Virtual StudioLive — 3

1.5 — 4

2.0 — 5

2.1 — 5

2.2 — 7

2.3 — 9

2.4 MIDI — 10

3.0 — 11

3.1 — 11

3.2 Windows — 12

3.3 Mac OS X — 14

3.4 AudioBox 22/44VSL — 15

4.0 : Virtual
StudioLive Studio One Artist — 17

4.1 Virtual StudioLive — 17

4.1.1 Virtual StudioLive: — 17

4.1.2 Virtual StudioLive: — 19

4.1.3 Virtual StudioLive: Overview
Fat Channel Zoom — 20

4.1.4 VSL:
— 21

4.1.5

VSL — 28

4.1.6

VSL
— 29

4.2

Studio One Artist — 32

4.2.1

— 32

4.2.2

— 37

4.2.3

MIDI — 38

4.2.4

— 41

4.2.5

— 43

4.2.6

MIDI- — 44

4.2.7

— 45

5.0

— 47

5.1

— 47

5.1.1

— 47

5.1.2

— 47

5.1.3 USB

— 47

5.1.4

— 48

5.2

— 51

5.2.1

— 51

5.2.2

— 52

5.2.3

:
— 56

5.3

— 59

5.3.1

? — 59

5.3.2

:

5.3.3

— 61

— 64

Virtual StudioLive
Studio One Artist
SL Remote,

5.4 - — **67**

5.4.1 — **67**

5.4.2 — **67**

5.5 — **68**

5.5.1 — **68**

5.5.2 — **69**

5.5.3 — **69**

6.0 — **70**

6.1 AudioBox 22VSL — **70**

6.2 AudioBox 44VSL — **72**

7.0
— **74**

7.1 — **74**

7.2 PreSonus
AudioBox — **75**

— **76**

1.0

1.1



PreSonus Audio Electronics

PreSonus AudioBox™ 22/44VSL.
AudioBox 22/44VSL

XMAX™

USB 2.0 (2x2/4x4

); MIDI

/ ; Fat

Channel 3-

, , ,
, , ,
, , ,

AudioBox 22/44VSL

USB 2.0,

PreSonus AudioBox 22/44VSL,

1-225-216-7887 9 17

PreSonus Audio Electronics

AudioBox 22 / 44VSL!

AudioBox,

1.2

AudioBox 22VSL

- 24 /96 XMAX
- 2
- 2 (AudioBox 44VSL)
- MIDI /
- -
- (108)
- USB 2.0 2x2 / 4x4 /
- -
- -
- -
- Virtual
- StudioLive™
 - Studio One™ Artist
 - Cubase, Digital Performer, Logic, Nuendo, Pro Tools 9+, Sonar, Studio One,
 - Mac OS X® Windows®

1.3

Studio One Artist

- PreSonus
Studio One Artist, 4 , ,
- Studio One Artist 4.1
Studio One Artist
- DVD .
-
- : (Ampire),
(Analog Delay, Beat Delay), (Redlight Dist), (Channel Strip,
Compressor, Gate, Expander, Limiter, Tricomp), (Channel Strip, Pro EQ),
(Autofilter, Chorus, Flange, Phaser, X-Trem), (MixVerb, Room Reverb)
(Binaural Pan, Mixtool, Phase Meter, Spectrum Meter, Tuner)
- 4 , , : Presence,
Impact, SampleOne,
Mojito
- -
- -
- -
- -
- Mac OS X® Windows®

1.4

Virtual StudioLive

Virtual StudioLive -

- drag-and-drop.
-
-
- Fat Channel
- StudioLive 16.0.2 Fat Channel
-
-
-
-
- 3-
-
-
-
- 32
-
-
-
-
- Fat Channel
-
-

Virtual StudioLive
Studio One Artist
SL Remote,

1
1.5

PreSonus AudioBox™ 22/44VSL

1.5


, , :
PreSonus AudioBox 22VSL 44VSL USB 2.0



USB 1,8 (6 6)



(AudioBox 44VSL)



- DVD-
- CD

PreSonus Studio One Artist

PreSonus Virtual StudioLive

AudioBox

2.0

2.1



AudioBox 22/44VSL
PreSonus XMAX™,
XMAX

AudioBox 22VSL (

AudioBox 44VSL)

1/4

XLR.

TS

1/4

1 2

(, - .).

, AudioBox 22/44VSL

(AudioBox 44VSL).
AudioBox 44VSL 1/4" 3 4

TRSTRS

CD/DVD

()

AudioBox 22/44VSL,



AudioBox 22/44VSL.



48

48 AudioBox 22/44VSL

48V.



XLR

- 1 =
2 = +48
3 = +48



Input Gain/Trim (/).

- XLR / TS 1/4" : 80
(-15/-30 +65/50)
- TRS 1/4" (40 (-20 +20) AudioBox 44VSL):



0 dBFS. ().

AudioBox 22/44VSL XMAX™



Mixer ().

(playback),

12

playback

Mixer VSL.

Virtual StudioLive,



Phones (). Phones

"11",

Main. Main
(Main Output),

-80 0




Power (22VSL)/USB Sync (44VSL).

USB 2.0.

AudioBox 44VSL:

USB


2.2

Phones ().



Main Out ().


AudioBox 22/44VSL.
Main,



Line Outputs () ()
AudioBox 44VSL.

DJ

1 2
3 4




MIDI I/O (/). MIDI
". MIDI
MIDI , MIDI
; ,
,
, (,).

AudioBox 22/44VSL.
MIDI



USB 2.0.
AudioBox 22/44VSL
USB,

USB
. AudioBox 22VSL




Power Input (

AudioBox 44VSL).


AudioBox 44VSL. AudioBox 44VSL

USB.

2.3

Virtual StudioLive
Studio One Artist
SL Remote

2.4 MIDI



3.0

AudioBox 22/44VSL

USB 2.0

3.1

PreSonus Studio One Artist and Virtual StudioLive*.

Macintosh

- Mac OS X 10.6
- :
 - : Intel® Core™ Duo, 2 GB RAM
 - : Intel Core 2 Duo Intel iCore
 - , 2 GB RAM

Windows

- (32 64):
 - Windows 7, Vista
- :
 - : Intel Core Duo AMD Athlon™ X2, 2 GB RAM
 - : Intel Core 2 Duo AMD Athlon X4
 - , 4 GB RAM

* www.presonus.com.

Virtual StudioLive
Studio One Artist
SL Remote,

3.2

Windows

AudioBox
22/44VSL
USB 2.0

AudioBox,
,

AudioBox


AudioBox 22/44VSL

CD-

Windows Vista:


Windows,

" ("Install this driver software anyway").



1.

" " (Next).




2.

StudioLive.

AudioBox Virtual


" " (Next).



3.

AudioBox,

"Install Driver" ().



4.

"Next" ()



5.

"Finish" ()

6.


22/44VSL

AudioBox

3.3


Mac OS X

AudioBox 22/44VSL,



1.

"Continue" ()



2.


Virtual StudioLive.

(Applications)

AudioBox VSL.

Dock.

"Install" ().



3.

22/44VSL

Mac USB

AudioBox 22/44VSL!

AudioBox

3.4**AudioBox 22/44VSL**

Studio One Artist

5.2

AudioBox 22/44VSL

Core Audio ASIO.

AudioBox 22/44VSL

Apple Logic Pro/Express 7+:

1. Logic Pro/Express.
2. Logic | Preferences | Audio.
3. Devices ().
4. Core Audio Enabled ().
5. PreSonus AudioBox 22(44)VSL
6. Logic. "try (re)launch."
7. AudioBox 22/44VSL / Logic, Options | Audio | I/O Labels.
8. "Provided by Driver." (, AudioBox 22/44VSL.)
9. AudioBox 22/44VSL.

Steinberg Cubase 4+

1. Cubase.
2. Devices | Device Setup .
3. Device Setup () "VST Audio System".
4. PreSonus AudioBox 22(44)VSL ASIO Driver.
5. AudioBox 22/44VSL "Switch" ().
6. Devices | VST Connections

Cakewalk Sonar 6+

1. Sonar.
2. Options | Audio... Advanced.
3. Driver Mode "ASIO." (WDM, ASIO,)
4. "OK".
5. Sonar
6. Options | Audio... Drivers.
7. , "PreSonus AudioBox 22(44)VSL."
8. Options | Audio... General.
9. , Playback Timing Master "PreSonus AudioBox... DAW Out 1."
10. , Recording Timing Master "PreSonus AudioBox... Mic/Inst 1."

Ableton Live 5+

1. Ableton Live
2. Options | Preferences | Audio.
3. Driver Type (): Asio | Audio Device: ASIO PreSonus AudioBox 22(44)VSL
4. Input Config ():
5. OutputConfig ():
6. , Live. AudioBox 22/44VSL

ProTools 10+

1. ProTools.
2. Setup | Hardware Peripherals. AudioBox 1818VSL OK.
3. Setup | Playback Engine OK. AudioBox 1818VSL

4.0

: Virtual StudioLive Studio One Artist

AudioBox 22/44VSL

Virtual StudioLive™ (VSL)
Studio One™ Artist.

4.1 Virtual StudioLive

Virtual StudioLive -

StudioLive 16.0.2. VSL

Fat Channel VSL

VSL

Fat Channel,
Fat Channel

AudioBox 22/44/1818VSL.

Mixer

"Do Not Show Again".



4.1.1 Virtual StudioLive:

VSL Setup

(user preferences).


Setup,

Setup

VSL.

Meter Decay

Device Widow.



VSL

Normal (

).

Slow Meter

Fast Metering

Meter Peak Hold

Meter Peak Hold:

VSL

Meter Post Fader

Meter Post Fader:

VSL

VSL

Run at Startup (Windows)

Virtual StudioLive.

Run at startup:

, VSL

Windows.

Mac

VSL

Dock


Options>Open at Login (>).

VSL

DAW,

Sample Rate (OS X)

44.1, 48, 88.2, 96




AudioBox,

Windows

Performance (OS X)

VSL




: Fastest

- Fastest:
- Normal:
- Safe:

VSL 1
VSL 2
VSL 4

Normal

ASIO Buffer Size (Windows)



2048

64 (44.1 48) 128 (88.2 96)

ADAT In Mode:

64

128

256

512

1024

2048

(11-12)

, 512

Mac

VSL (Windows)

(Mac OS X),
ASIO Core Audio.

4.1.2 Virtual StudioLive:

VSL ,
Browser (). VSL , Studio One.
Fat Channel

AudioBox 22/44VSL.



VSL

- SCENE.

Fat Channel

(mute) (solo)

- FAT CH.


Fat Channel. VSL 50

Fat Channel,

- FX.

VSL 30
PreSonus.

Add New



Add New ().

).

Remove**Add New****Remove.****Show/Hide Browser**

/

(

AudioBox 44VSL).

**Browser".**

,

"Hide**Browser"**

VSL.

"Show**4.1.3 Virtual StudioLive: Overview Fat Channel Zoom****VSL**

Virtual StudioLive.

VSL,

Overview.



3 4 (

AudioBox 44 VSL)

•

•

•

•

•

solo mute

Fat Channel

Fat Channel Zoom

Fat Channel

•

(Fat Channel Zoom)

AudioBox 22VSL:



AudioBox 44VSL:



4.1.4

VSL :

VSL -

16.0.2

StudioLive

VSL

AudioBox 22/44VSL.

VSL "DAW"
(DAW).

DAW

Virtual StudioLive

VSL On/Off

/

VSL

AudioBox

VSL On/ Off


Mixer,

DAW. VSL



VSL
"VSL",

Mixer






Fat Channel.
Fat Channel Post,

Phase Reverse



(180°).



VSL

Post Button



Fat Channel.

Fat Channel.

Post.

Fat Channel

DAW.

DAW,


Fat Channel (

).

DAW.

Post

VSL

High Pass Filter Freq

18 1,3

5.3.1.



High Pass Filter

VSL

-6 /

Gate On/Off**Gate Threshold**

Gate Threshold ()

0 -84

Threshold,
Gate Graph.**Compressor On/Off****Auto Mode**

()

Attack () Release

10

150

Threshold



-56 0

Ratio



ratio 2:1, 2
1
1:1 14:1.

Attack



0,2 150

Release



release
40 1000

Makeup Gain



Makeup Gain
Makeup Gain 0 () +28 .

Limiter On/Off



(ratio) ∞:1.

0 dBFs.

Equalizer On/Off**Low EQ On/Off****Low EQ Frequency**

36 465

Low EQ Gain

-15 +15

Low Shelf EQShelf
Shelf*Center Frequency***Mid EQ On/Off**

Mid EQ Frequency



380 5

Mid EQ Gain



-15 +15

Mid Hi Q



Q -
Q Q 0,55.
Q 2,0,
Hi Q

Q

Hi Q

High EQ On/Off



High EQ Frequency





1,4 18

High EQ Gain



-15 +15





(Master)

Overview.
FX Type ()

4.1.6

VSL

Virtual StudioLive

StudioLive 16.0.2.

Fat Channel,



VSL

(Main)

VSL, Main Phones,
AudioBox 22/44VSL.

2

3 4 (AudioBox 44VSL)

AudioBox 44VSL

3 4.

(channel send),



3 4.

3 4.

Line 1 2,

3 4.

3 4.

3 4.

Output 3

Output

4

3 4.

29

3

Fat Channel



AudioBox 22/44VSL

Fat Channel DAW,
VSL. Fat Channel Downward Expander ()
, 3- 5.2 5.3.

Overview VSL

Fat Channel

Fat Channel : Gate (), Compressor (),
EQ (). Fat Channel AudioBox 22VSL)

FAT CHANNEL GATE OFF COMPRESSOR OFF EQ OFF X

FILTER NOISE GATE

Phase FREQ 160.3 Hz THRESH -35 dB

FX

4:

FAT CHANNEL FX

User Presets - +

- M DEL-Chase Me
- M DEL-Dubtastic
- M DEL-Echo Chamber
- M DEL-Grand Canyon
- M DEL-Long Delay
- M DEL-Medium Delay

FX ().

Reverb Reverb

Pre delay Room Size Damping Width

Pre delay Room Size Damping Width

M DEL-Medium Delay
M DEL-Short Delay
M DEL-Single Repeat
M DEL-Slap Back
M DEL-Slight Echo
REV-Ambience
REV-Arena
REV-Bedroom
REV-Cathedral
REV-Closet
REV-Large Hall
REV-Medium Hall

A B

3 4

AudioBox 44VSL -



- Reverb (): Pre delay ().

- Reverb: Room size ().

- Reverb: Width ().

- Delay (): Delay Time ().

- Delay: Feedback ().

- Reverb and Delay (): Damping ().



AudioBox 44VSL:


FX A FX B

(Out 3,4 Main)

FXA FXB.

4.2

Studio One Artist



AudioBox 22/44VSL

Studio One Artist.

, Studio One Artist

Studio One Producer

Studio One Professional.

Studio One,

<http://studioone.presonus.com/>.

4.2.1

AudioBox

22/44VSL

PreSonus Studio One Artist,

Studio One Artist,

DVD-

Studio One



DVD-

Studio One Artist,

Windows:


• Mac:
Applications ()Studio One Artist
Mac.



1. Studio One Artist ,
 Studio One. Activate ()
 Upgrade ().




2. Studio One,
 "Create New Account" (),
 "Activating Studio One Artist Offline."
 PreSonus,
 "Activating Studio One Artist On Line."



3. PreSonus.
 PreSonus.
 PreSonus,
 PreSonus
 PreSonus.



4. ,
 ,
 PreSonus.

Studio One Artist

Studio One Artist.


Activate Online


Studio One Artist.

Activate

Studio One Artist

1.


<http://www.presonus.com/registration/>2.
Software Registration ().3.
"Submit" ().4.
"My Software" ().



5. ““Download License”” ()
“Studio One 2 Artist.license”.



6. Studio One Artist.
Activate Studio One
“Activate Offline”.



7. “Studio One 2 Artist.license” Offline Activation.


Studio One Artist



Studio One Artist

- Studio One Artist
Studio One.

1. “Install content from DVD or local folder.”
()
DVD ()



2.

DVD,

DVD-

Install Packets (


),
Done ().*Studio One 2> Studio One Installation.*

(Celemony Melodyne Trial, Native Instruments Komplete Player).



Native Instruments Komplete

"Done".



4.2.2

Studio One Artist
AudioBox 22/44VSL
Studio One Artist
Start.

PreSonus.

PreSonus.

Studio One Artist

pdf-

Studio One Artist

Setup

MIDI

Setup.

Studio One Artist

PreSonus,



Studio One
"PreSonus AudioBox 22/44VSL",
Configure Audio Devices (),
Audio Setup Options ().

Audio Device () "PreSonus
AudioBox." Apply ()

PreSonus AudioBox

MIDI

MIDI

4.4.

4.2.3 MIDI

External Devices () Studio One Artist
MIDI ,
MIDI

Studio One Artist, MIDI

MIDI USB MIDI-

MIDI

MIDI

MIDI

MIDI
Studio One

Artist

Keyboards (),


MIDI
Studio One Artist

MIDI (, , ,) - MIDI

Instrument,

MIDI

Setup



1. 22/44VSL MIDI Out
MIDI In
USB MIDI MIDI
AudioBox

2. () Configure External Devices
Setup External Devices.



Add ().



3. Add Device ().

4. New Keyboard.

5. , MIDI

MIDI

16.




6. Receive From ()
, Studio One Artis
MIDI , AudioBox 22/44VSL.

Send To ()
(AudioBox 22/44VSL),
MIDI

MIDI , Studio One,
MIDI

MIDI , Studio One,
MIDI

MIDI , Studio One,
MIDI



7. Default
Instrument Input ().

Studio One Artist.
OK.

External Devices

4.2.4.

MIDI


MIDI (, MIDI- .)
MIDI

,
. Studio One Artist

Instruments.

1. MIDI
MIDI
MIDI

AudioBox 22/44VSL



2. External Devices (). Add



3. Add Device ().


“New Instrument.”

4. , MIDI

MIDI




16.



6. Send To ()
 MIDI , Studio One Artist
 MIDI , AudioBox 22/44VSL.
 Receive From () MIDI
 (AudioBox 22/44VSL), Studio One Artist
 MIDI ,
 Studio One,
 External Devices.
 Studio One Artist.

Studio One Artist.

4.2.4



1. "Create a new Song"
 ().



2. (templates). AudioBox 22VSL 44VSL




4. Empty Song ().

Notation Bars (), Seconds (), Samples (),
 Frames().

5. Stretch Audio Loops to Song Tempo
 (),
 BPM ()



6. Song, **Audio Setup ()**
Studio One | Options... (Windows) Studio One |
Preferences (Mac) Audio Setup.



7. Song Setup (),
Song Setup, / **Song I/O Setup. ()**.

8. **Song>Song Setup** "Audio I/O Setup."

9. ,
AudioBox 22/44VSL.

, Remove ().

, Enter.

10. ,
Studio One Artist,
"Make Default".



11. Outputs (),
AudioBox 22/44VSL.

AudioBox 22/44VSL.

12. ().
Audition ,

Studio One Artist.

13. ,
Studio One Artist, "Make Default".

14. ,
MIDI

Studio One Artist, !

4.2.5



1. Arrange ()
Add Tracks
().
Add Tracks.


2. (Mono Audio (), Stereo
Audio (), Folder (), Instrument (),
Automation ()),

3. , , , ,

4. Track | Add Tracks for All Inputs ().

5. , , , ,

1
AudioBox 22/44VSL. Studio One Artist



6.

AudioBox.
22/44VSL

AudioBox
,
AudioBox.

DVD

Studio One Artist.




4.2.6 MIDI-



1. Add Tracks ().
(Instrument)



2. MIDI , , ,
MIDI , , ,
3. , , ,
4. , , ,
MIDI , , ,
Output. , , ,
MIDI , , ,
MIDI



5. Add Track Inspector.
6. Inspector Bank
Program.



MIDI

AudioBox,

(

,

MIDI

)


,

4.2.7



Edit (Arrange ()
MIDI Piano-roll
Mix
Browse


, MIDI , (. pool)




Browse Instrument -

Arrange.

Studio One Artist



Effects



MIDI

Arrange.

(part)

5.0

5.1

AudioBox 22VSL AudioBox 44VSL

5.1.1

(DI).

22/44VSL

48

AudioBox
XLR.

5.1.2

5.1.3 USB

USB

USB

AudioBox 22/44VSL

5.1.4

AudioBox 22/44VSL.



2,5 - 5





12

20

30

XY

(

)



2,5 - 5

AudioBox 22/44VSL.

AudioBox.

Virtual StudioLive
Studio One Artist
SL Remote,

(XY)



XY.

2-2,5

45

()



5.2

AudioBox 22/44VSL
 Virtual StudioLive (VSL).
 , VSL
 Fat Channel.

PreSonus
 ,
 VSL Fat Channel.

5.2.1

?

, +24 dBu,
 -92 dBu, 24+96 = 116

-50 dBu +10 dBu. 60 . 60
 ,
 +10 dBu 1000 , -50 dBu!
 ,
 -10 dBu +10 dBu, 20 .

?

20 .
 ,
 -30 dBu +10 dBu. 40 .
 , +10 dBu
 -30 dBu

10 .
 , +5 dBu.
 0 dBu +10 dBu.

?

5.2.2

2:1
10:1
().
,
(,).
,
()
,
,
/

Threshold (). Threshold
,
,
1:1).
Ratio (). ratio -
, ratio
2:1,
1
0,5 .
0 , ratio
0 ,
0

Attack ().

() ,
(ratio).

Release (). release

() ,

Hard/Soft Knee (/).

().

Auto ().

Attack Release

Makeup Gain ().

Makeup Gain

().

Sidechain ().

5 , 10

Threshold.

Ratio ().

2:1 , 2
1 , 4:1

Threshold () , Gate Threshold ()

(range).

),
Attack ().

Hold ().

Release ().

Range ().

, 0 , -60 ,
60 ,
Key Listen ().

(attack). (hold)

(release).

range,

5.2.3

PreSonus BlueMax.
VSL.

Soft (). ratio

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -8,2 | 1,8:1 | 0,002 | 38 |

Medium ().
Soft,

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -3,3 | 2,8:1 | 0,002 | 38 |

Screamer ().

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -1,1 | 3,8:1 | 0,002 | 38 |

Snare/Kick (/).

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -2,1 | 3,5:1 | 78 | 300 |

Left/Right (Stereo) Overheads ()

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -13,7 | 1,3:1 | 27 | 128 |

Electric Bass (-)

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -4,4 | 2,6:1 | 45,7 | 189 |

Acoustic Guitar ()

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -6,3 | 3,4:1 | 188 | 400 |

Electric Guitar () (crunch).

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -0,1 | 2,4:1 | 26 | 193 |

Piano ()

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -10,8 | 1,9:1 | 108 | 112 |

Synth ()

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -11,9 | 1,8:1 | 0,002 | 85 |

Orchestral ()

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| 3,3 | 2,5:1 | 1,8 | 50 |

Stereo Limiter ("brickwall,"

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| 5,5 | 7,1:1 | 0,001 | 98 |

Contour.

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -13,4 | 1,2:1 | 0,002 | 182 |

Squeeze.

"Tele/Strat".

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| -4,6 | 2,4:1 | 7,2 | 93 |

Pump.

| Threshold | Ratio | Attack | Release |
|-----------|-------|--------|---------|
| 0 | 1,9:1 | 1 | 0,001 |

5.3

Fat Channel VSL

3-

5.3.1

?

iPod.

Virtual StudioLive
Studio One Artist
SL Remote,

(3 7).
StudioLive 24.4.2,

Q,

StudioLive 16.4.2, 16.0.2 AudioBox 22/44VSL,

(High Low Q).

Q

Q


Q,

Q,

(Q)

(notch

1)
filter.

5
5.3

(2 - 4).

(4 - 6).

5

(6 - 16).

5.3.2

?


(, , , ,).

15

1

| | | | | |
|---|-----|---|---------|---|
| | 7 | | 8 | |
| | 2 | | 3 | |
| | 1 | | 200-400 | , |
| | 80 | | | |
| | 1-2 | , | 5 | |
| | 300 | , | 100 | |
| | 1-2 | | 3 | |
| | 80 | | 125 | |
| | 2-3 | , | 5 | |
| | 200 | , | 125 | |
| - | 1 | | 600 | |
| | 125 | , | 80 | |
| | 600 | | 2-5 | |
| | 200 | , | 125 | |
| | 1 | , | 2 | |
| | | | 150-200 | |
| | | | 80 | |
| | 400 | | 2-5 | |
| | 80 | , | 60-125 | |
| | 300 | , | 2-5 | |
| | | | 80-200 | |
| | 1 | , | 7-8 | |
| | | | 8-12 | |
| | | | 15 | |
| | 1 | | 8-12 | |
| | 120 | | 2 | |
| | 3 | | 2 | |
| | 120 | | 400-600 | |

2



Virtual StudioLive
Studio One Artist
SL Remote,

5.3.3

VSL

Channel Strip.

4.1.5

5.2.3,

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|---------------|-------------------|------------------|-------------|-------------------|---------------------|----------------------|-----------------|
| ON | PEAK | 130 | -2 | ON | LOW | 465 | -2 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|------------------|-----------------|----------------------|----------------|--------------|------------------|------------------|------------|
| ON | LO | 2.4 | +2 | ON | PEAK | 6.0 | +8 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|---------------|-------------------|------------------|-------------|-------------------|---------------------|----------------------|-----------------|
| ON | SHELF | 155 | +4 | ON | LOW | 465 | +6 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|------------------|-----------------|----------------------|----------------|--------------|------------------|------------------|------------|
| ON | LO | 1.4 | +6 | ON | PEAK | 4.2 | +2 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|---------------|-------------------|------------------|-------------|-------------------|---------------------|----------------------|-----------------|
| ON | PEAK | 225 | -2 | ON | HI | 960 | 0 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|------------------|-----------------|----------------------|----------------|--------------|------------------|------------------|------------|
| ON | LO | 2.0 | +2 | ON | PEAK | 7.2 | +4 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|---------------|-------------------|------------------|-------------|-------------------|---------------------|----------------------|-----------------|
| ON | PEAK | 155 | +2 | ON | HI | 265 | -6 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|------------------|-----------------|----------------------|----------------|--------------|------------------|------------------|------------|
| ON | HI | 2.4 | -2 | ON | SHELF | 7.2 | +4 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|---------------|-------------------|------------------|-------------|-------------------|---------------------|----------------------|-----------------|
| ON | PEAK | 130 | -4 | ON | LOW | 665 | +4 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|------------------|-----------------|----------------------|----------------|--------------|------------------|------------------|------------|
| ON | LO | 1.6 | +4 | ON | SHELF | 4.2 | +4 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|---------------|-------------------|------------------|-------------|-------------------|---------------------|----------------------|-----------------|
| ON | SHELF | 108 | -2 | ON | LOW | 385 | -2 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|------------------|-----------------|----------------------|----------------|--------------|------------------|------------------|------------|
| ON | LO | 2.9 | +2 | ON | SHELF | 8 | 4 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|---------------|-------------------|------------------|-------------|-------------------|---------------------|----------------------|-----------------|
| ON | PEAK | 108 | +4 | ON | HI | 265 | -4 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|------------------|-----------------|----------------------|----------------|--------------|------------------|------------------|------------|
| ON | LO | 1.6 | 0 | ON | SHELF | 6.0 | +4 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|---------------|-------------------|------------------|-------------|-------------------|---------------------|----------------------|-----------------|
| ON | SHELF | 36 | -8 | ON | HI | 130 | +4 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|------------------|-----------------|----------------------|----------------|--------------|------------------|------------------|------------|
| ON | LO | 2.0 | +4 | ON | SHELF | 4.2 | 0 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|---------------|-------------------|------------------|-------------|-------------------|---------------------|----------------------|-----------------|
| ON | PEAK | 155 | +4 | ON | LOW | 665 | +2 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|------------------|-----------------|----------------------|----------------|--------------|------------------|------------------|------------|
| ON | LO | 2.0 | 0 | ON | SHELF | 6.0 | +4 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|------------|----------------|---------------|----------|----------------|------------------|-------------------|--------------|
| ON | PEAK | 320 | +6 | ON | LOW | 960 | 0 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|---------------|--------------|-------------------|-------------|-----------|---------------|---------------|---------|
| ON | HI | 3.5 | +4 | ON | SHELF | 12 | 0 |

| LOW ON/OFF | LOW PEAK/SHELF | LOW FREQ (Hz) | LOW GAIN | LOW MID ON/OFF | LOW MID HI/LOW Q | LOW MID FREQ (Hz) | LOW MID GAIN |
|------------|----------------|---------------|----------|----------------|------------------|-------------------|--------------|
| ON | SHELF | 108 | -2 | ON | LO | 665 | +2 |

| HI MID ON/OFF | HI MID LO/HI | HI MID FREQ (kHz) | HI MID GAIN | HI ON/OFF | HI PEAK/SHELF | HI FREQ (kHz) | HI GAIN |
|---------------|--------------|-------------------|-------------|-----------|---------------|---------------|---------|
| ON | LO | 2.9 | +2 | ON | PEAK | 7.2 | +4 |

5.4

VSL AudioBox 44VSL aux
3 4, FX A FX B.

5.4.1

(-).()
)
Aux 1.
Fat Channel
16

Aux 1.

5.4.2

VSL

20-30%.

FX A FX B

5.5

VSL

Studio One Artist

5.5.1

- Decay () Decay -

1 3

- Predelay ()

() predelay

- HF and LF decay ().

(LF) (HF)

5.5.2

(delay)

Delay Time (

).

30 100
(slap-back),

Feedback (

).

5.5.3

Chorus ()

LFO Speed and Width (

LFO):

(LFO).

Depth ():

depth

Phase ()

0 360

Flange ()

6.0**6.1 AudioBox 22VSL**

| | | | | | | | |
|---|--|--------|-------|------------|---------------------|---------------------|-----------|
| | | | , XLR | , | | | |
| . | | | -129 | , | 20 | A. | , |
| . | | | =40 | , | | | |
| . | | | 20 | -20 | , +/- 0,3 | , | |
| . | | + | | | 0,005%, 0 dBu, 1 | 20 | , |
| . | | | | | | A | , |
| / | | | 94 | , 0 dBu, 1 | 20 | , | |
| | | | | | | | , |
| | | | -15 | | +65 | | |
| . | | | | | +10 dBu, < 0,5% THD | | |
| . | | | | | 1,7 | | |
| . | | | | | +48 | | , 10 |
| | | (1 2) | | | | | |
| | | | | | , 1/4' TS, | | |
| . | | | | | 20 | -20 | , +/- 0,3 |
| . | | | . | | =0,006%, 0 dBu, 1 | 20 | , |
| . | | + | | | | A | , |
| / | | | | | 89 | , 0 dBu, 1 | 20 |
| | | | | | | | , |
| | | | | | -30 | | +50 |
| . | | | | | | +15 dBu, < 0,5% THD | |
| . | | | | | 1 | | |
| . | | | . | | | | |
| | | | | | 1/4' TRS, | | |
| . | | | | | 30 | / | 60 |
| . | | | | | 20 | -20 | , +/- 0,5 |
| . | | + | | | 0,08%, 1 | A | , |
| / | | | | | | | 20 |
| | | | | | 90 | , 1 | , |
| | | | | | | | 20 |

| | | |
|--------|-----------------------|--------------------|
| | | 1/4' TRS, , , |
| | 20 - 20 | , +/- 0,2 |
| . | + | 0,002%, 1 , 20 , A |
| / | 107 , 1 , . , | , 20 , . |
| | | +10 dBu |
| | | 51 |
| | | : |
| (AB22) | | USB, 5 . , 500 |
| | | : |
| | | USB 2.0 |
| | 24 | |
| | 44,1 , 48 , 88,2 , 96 | |
| . | 6 , | |
| | 114 , . 48 , | A |
| | 114 , . 48 , | A |
| MIDI / | | DIN, 5 |

Virtual StudioLive
Studio One Artist
SL Remote

6.2

AudioBox 44VSL

| | | | | | | |
|---|---------------------|-------------|---------------------|----|------|---|
| | | | XLR | | | |
| . | -133 | , | =40 | 20 | A. | , |
| . | 20 | - 22 | , +/- 0,25 | , | . | , |
| . | + 0,002%, +4 dBu, 1 | 22 | , | A | , | , |
| . | / 97 | , +4 dBu, 1 | 22 | , | , | , |
| | | -15 | +65 | | | |
| . | | | +16 dBu, < 0,5% THD | | | |
| . | | | 1,7 | | | |
| . | | | +48 | . | , 32 | |
| | (| 1 | 2) | | | |
| . | | | , 1/4" TS, | | | |
| . | 20 | - 22 | , +/- 0,25 | , | . | , |
| . | + 0,003%, +4 dBu, 1 | 22 | , | A | , | , |
| . | / 89 | , +4 dBu, 1 | 22 | , | , | , |
| | | -30 | +50 | | | |
| . | | | +21 dBu, < 0,5% THD | | | |
| . | | | 1 | | | |
| | (| 3 | 4) | | | |
| . | | | , 1/4" TRS, | | | |
| . | 20 | - 22 | , +/- 0,25 | , | . | , |
| . | + 0,002%, +4 dBu, 1 | 22 | , | A | , | , |
| . | / 98 | , +4 dBu, 1 | 22 | , | , | , |
| | | -20 | +20 | | | |
| . | | | +21 dBu, < 0,5% THD | | | |
| . | | | 10 | | | |

1/4' TRS, ,
120 / 60
20 - 20 , +/- 0,5 , .
+ 0,01%, 1 , . A ,
20 , ,
/ 96 , 1 , . , ,
20 , ,

1/4' TRS, , ,
20 - 20 , +/- 0,25
+ 0,003%, 1 , 22 ,
A ,
/ 109 , 1 , 22 ,
. ,
+10 dBu, < 0,5% THD
51

2,1 , 12 . , 1

USB 2.0
24
44,1 , 48 , 88,2 , 96
6 ,
114 , . 48 , A
114 , . 48 , A
MIDI / DIN, 5

7.0

7.1

(DAW)
PreSonus

PreSonus

Studio One™
AudioBox,
AudioBox VSL

(www.presonus.com),

9 17
PreSonus
PreSonus
support@presonus.com.

AudioBox

, USB
USB
USB 2.0.

,
AudioBox.
AudioBox

AudioBox VSL

AudioBox VSL

AudioBox, USB

,
AudioBox.

VSL

, VSL
AudioBox
Fat Channel,

VSL AudioBox VSL

, mixer
VSL.

VSL

, mixer
VSL.
DAW
AudioBox
DAW
AudioBox VSL,
DAW.

7.2

PreSonus AudioBox

PreSonus Audio Electronics, Inc.

(1)

14

PreSonus

PreSonus

PreSonus

PreSonus

PreSonus

PreSonus

PreSonus

PreSonus Audio Electronics, Inc.
7257 Florida Blvd.
Baton Rouge, LA 70806

Virtual StudioLive
Studio One Artist
SL Remote

| | | | | |
|-------------------------|----|-----------------|-------|----------------|
| | | | | C |
| 54, 55 | | 24 | | 67 |
| | | 52-53 | | 30, 67 |
| Studio One Artist 37 | | 56 | | 53, 55 |
| | , | | 19 | |
| Studio One Artist 42-43 | | 54 | | VSL 19 |
| 24 | | 54 | | 28 |
| | | | | 22 |
| 54 | | 25, 53 | | 22 |
| | | | | . |
| 54, 55 | | Makeup Gain 54 | | . |
| | | MIDI 38 | | Fat Channel 20 |
| | | MIDI 40 | | 24 |
| 56 | | | | |
| 24, 52 | | | 18 | 62 -63 |
| 56 | | 69 | | 18 |
| | 55 | | | |
| | | | | . |
| 51 | | Ableton Live 16 | | 59 |
| 55 | | Cubase 15 | | 59 |
| | | Logic 15 | | 60 |
| 59 | | ProTools 16 | | VSL 26 |
| | | Sonar 16 | | . |
| | | | | 54 |
| 68 | | 19 | | 55 |
| 69 | | 20 | | |
| | 68 | Fat Channel 19 | | |
| 69 | | 19 | | |
| | | | 6, 47 | |
| Fat Channel 28 | | 46 | | |
| 29 | | Post 23 | | |
| 22 | | 53, 55 | | |
| | 18 | | | |
| | | | (| |
| | | | 18 |) 19 |
| Studio One 46 | | | , | |
| | | | 23 | |
| | | | 68 | |
| 23 | | | | |
| | 17 | | | |
| 18 | | | | |
| | 18 | | | |

FC

: PreSonus Audio Electronics

: 7257 Florida Blvd., Baton Rouge, LA
70806 USA

: 225-216-7887

, AudioBox™ 22VSL/AudioBox 44VSL

15 FCC.

1. , ;
2. , ,

 **PreSonus**


Baton Rouge • USA • www.presonus.com

© 2012 PreSonus Audio Electronics, Inc.
Audio Electronics, Inc.. Studio One Capture
. Windows -

PreSonus, StudioLive, XMAX, QMix, AudioBox
PreSonus Software, Ltd. Macintosh -
Microsoft, Inc.,

PreSonus
Apple, Inc.,

AudioBox™ 22/44VSL



15 FCC (

)

PreSonus Audio Electronics

FCC

/ B (,),

ATTENTION — Le present appareil numerique n'emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de classe A/de classe B (selon le cas) prescrites dans le reglement sur le brouillage radioelectrique edicte par le ministere des communications du Canada.



7257 Florida Boulevard • Baton Rouge,
Louisiana 70806 USA • 1-225-216-7887
www.presonus.com

Part# 820-AB0013-D